


# Browning Automatic-5 Shotgun



- |                                   |                                          |                                         |
|-----------------------------------|------------------------------------------|-----------------------------------------|
| 1001 Action Spring                | 1147 Extractor, Left                     | 1325 Magazine Spring                    |
| 1003 Action Spring Follower       | 1150 Extractor, Right                    | 1330 Magazine Spring Retainer           |
| 1005 Action Spring Plug           | 1152 Extractor Pin, Left & Right         | 1335 Magazine Tube—5-Shot               |
| 1007 Action Spring Plug Pin       | 1159 Extractor Spring, Left              | 1344 Mainspring                         |
| 1010 Action Spring Tube           | 1160 Extractor Spring, Right Hand        | 1345 Mainspring Screw                   |
| 1017 Barrel Extension             | 1169 Firing Pin                          | 1346 Operating Handle                   |
| 1027 Breech Block                 | 1169 Firing Pin Stop Pin                 | 1359 Receiver                           |
| 1070 Carrier Dog                  | 1197 Friction Piece—Bronze               | 1378 Recoil Spring                      |
| 1075 Carrier Dog Follower         | 1205 Friction Ring                       | 1385 Safety Crossbolt, Right            |
| 1077 Carrier Dog Follower         | 1215 Friction Spring                     | 1390 Safety Ball                        |
| 1079 Carrier Dog Pin              | 1227 Hammer Assembly                     | 1405 Safety Sear                        |
| 1080 Carrier Dog Pin              | 1235 Hammer Pin                          | 1409 Safety Sear Pin                    |
| 1082 Carrier Dog Spring           | 1247 Link                                | 1410 Safety Sear Spring                 |
| 1083 Carrier Dog Spring           | 1252 Link Pin                            | 1414 Safety Sear Spring Follower        |
| 1086 Carrier Latch Assembly       | 1256 Locking Block                       | 1431 Sight Bead                         |
| 1092 Carrier Latch Button         | 1269 Locking Block Latch 2-Piece Carrier | 1435 Tang Screw for Pistol Grip Stock   |
| 1098 Cartridge Stop Pin           | 1275 Locking Block Latch Pin             | 1442 Trigger for Crossbolt Safety       |
| 1103 Carrier Screw                | 1277 Locking Block Latch Spring          | 1445 Trigger Pin                        |
| 1107 Carrier Spring Trigger Plate | 1280 Lock Screws                         | 1465 Trigger Plate for Crossbolt Safety |
| 1115 Cartridge Stop               | 1285 Magazine Cap                        | 1475 Trigger Plate Screw                |
| 1120 Cartridge Stop Spring        | 1297 Magazine Cutoff                     | 1480 Trigger Plate Screw, Rear          |
| 1122 Ejector & Ejector Rod        | 1305 Magazine Cutoff Spring              | 1486 Trigger Spr.—Pin Retained          |
| 1124 Ejector Spring               | 1310 Magazine Cutoff Spring Screw        | 1495 Trigger Spr. Retaining Pin         |
| 1126 Ejector Spring Retainer      | 1318 Magazine Follower                   | 1499 Magazine Adaptor—3-Shot            |
| 1127 Ejector—12 & Prewar 16       |                                          |                                         |
| 1136 Ejector Rivet                |                                          |                                         |