


BROWNING AUTO-5

Automatic 5
Shot - Shotgun
Standard, Light &
Magnum Models
12, 16 & 20
Gauge



**NOTE: Parts list & illustration
is for Post WWII Models.**

PART # DESCRIPTION

P011001	Action Spring All Gauges
P011003	Action Spring Follower All Gauges
P011005	Action Spring Plug All Gauges
P011007	Action Spring Plug Pin All Gauges
P011009	Action Spring Tube All Gauges
P011015	Barrel Extension Assembly, Magnum 12 Gauge
P011017	Barrel Extension Assembly, 12
P011022	Barrel Extension Assembly, 16
P011027	Breech Block 12M-12
P011032	Breech Block 16
P011036	Breech Block 20
P011040	Butt Plate All Gauges
P011042	Butt Plate Screws All Gauges
P011062	Carrier Assembly Magnum 12 Gauge
P011064	Carrier Assembly 2 Piece 12
P011066	Carrier Assembly 2 Piece 16
P011068	Carrier Assembly 2 Piece 20-20M
P011070	Carrier Dog 12M 12
P011071	Carrier Dog 16-20-20M
P011076	Carrier Dog Follower 12M-12
P011077	Carrier Dog Follower 16-20-20M
P011079	Carrier Dog Pin 12M-12
P011080	Carrier Dog Pin 16-20-20M
P011081	Carrier Dog Spring 12M-12
P011083	Carrier Dog Spring 16-20-20M
P011085	Carrier Latch Assembly Magnum 12 Gauge
P011086	Carrier Latch Assembly 12
P011089	Carrier Latch Assembly 16
P011090	Carrier Latch Assembly 20-20M
P011092	Carrier Latch Button 12
P011093	Carrier Latch Button 12M-16
P011094	Carrier Latch Button 20-20M
P011098	Cartridge Stop-Carrier Latch-Magazine Cutoff Pin
P011103	Carrier Screw All Gauges
P011107	Carrier Spring Trigger Plate Type 12M-12
P011111	Carrier Spring Trigger Plate Type 16-20-20M

PART # DESCRIPTION

P011115	Cartridge Stop 12M 12
P011117	Cartridge Stop 16-20-20M
P011120	Cartridge Stop Spring All Gauges
P011124	Ejector Spring Magnum 20 Gauge
P011125	Ejector Magnum 12 Gauge
P011126	Ejector Spring Retainer Magnum 20 Gauge
P011127	Ejector 12 & Prewar 16
P011134	Ejector 16-20
P011136	Ejector Rivet 12
P011142	Ejector Rivet 12M 16 20
P011147	Extractor Left 12M-12-16-20
P011148	Extractor Spring Follower Magnum 20 Gauge
P011149	Extractor Spring Magnum 20 Gauge
P011150	Extractor Right 12M-12-16-20
P011155	Extractor Pin Left & Right All Gauges
P011159	Extractor Spring Left 12M-12-16-20
P011160	Extractor Spring Right 12M-12
P011162	Extractor Spring Right 16-20
P011163	Extractor Spring Magnum 20 Gauge
P011164	Extractor Spring Follower Right 16-20
P011165	Firing Pin 12M 12
P011167	Firing Pin 16-20-20M
P011168	Firing Pin Stop Pin 12M 12
P011169	Firing Pin Stop Pin 16-20-20M
SRBJ.1	Forearm 5-Shot
P011195	Friction Piece Bronze Magnum 12 Gauge
P011197	Friction Piece Bronze 12
P011199	Friction Piece Bronze 16-20
P011205	Friction Ring 12M-12
P011207	Friction Ring 16-20-20M
P011215	Friction Spring 12
P011216	Friction Spring 16-20
*P011225	Hammer Assembly Magnum 12 Gauge
*P011228	Hammer Assembly- Lightweight 12
*P011232	Hammer Assembly Lightweight 16-20-20M
*P011235	Hammer Pin All Gauges

BROWNING AUTO-5 12,16 & 20 Ga.

PART #	DESCRIPTION
P011247	Link 12
P011251	Link 16-20
P011252	Link Pin 12M-12
P011254	Link Pin 16-20-20M
P011256	Locking Block 12M-12
P011261	Locking Block 16-20-20M
P011264	Locking Block Latch Magnum 20 Gauge
P011265	Locking Block Latch Magnum 12 Gauge
P011269	Locking Block Latch 2-Piece Carrier 12
P011272	Locking Block Latch 2 Piece Carrier 16-20
P011275	Locking Block Latch Pin All Gauges
P011277	Locking Block Latch Spring 12M-12
P011279	Locking Block Latch Spring 16-20-20M
P011280	Lock Screw All Gauges
P011285	Magazine Cap-W/O Swivel Eyelet 12M-12
P011287	Magazine Cap-W/O Swivel Eyelet 16-20-20M
P011292	Magazine Cap W/Swivel Eyelet 12-12M
P011294	Magazine Cap W/Swivel Eyelet 16-20-20M
P011295	Magazine Cutoff - Magnum 12 Gauge
P011297	Magazine Cutoff 12
P011298	Magazine Cutoff 16
P011299	Magazine Cutoff 20-20M
P011305	Magazine Cutoff Spring All Gauges
P011310	Magazine Cutoff Spring Screw All Gauges
P011318	Magazine Follower 12
P011319	Magazine Follower 16
P011321	Magazine Follower 20-20M
P011325	Magazine Spring 12M-12
P011329	Magazine Spring 16-20-20M
P011330	Magazine Spring Retainer 12M-12
P011333	Magazine Spring Retainer 16-20-20M
P011335	Magazine Tube 5-Shot 12M-12
P011339	Magazine Tube 5-Shot 16
P011343	Magazine Tube 5-Shot 20
P011344	Mainspring All Gauges
P011345	Mainspring Screw All Gauges
P011346	Operating Handle 12M-12
P011347	Operating Handle 16-20-20M

PART #	DESCRIPTION
P011375	Recoil Spring Magnum 12 Gauge
P011378	Recoil Spring 12
P011379	Recoil Spring 16
P011381	Recoil Spring 20
P011385	Safety Crossbolt Right All Gauges
P011386	Safety Crossbolt Left All Gauges
P011390	Safety Ball All Gauges
P011397	Sight Base-Rear-Buck Special 16
P011398	Sight Base-Rear-Buck Special 20-20M
P011399	Sight Body-Rear-Buck Special All Gauges
P011400	Sight Aperture-Rear-Buck Special All Gauges
P011401	Sight Adjusting Screw-Windage-Buck Special All Ga.
P011403	Sight Adjusting Screw-Elevation-Buck Spec. All Ga.
P011404	Sight Roll Pin-Buck Special All Gauges
P011405	Safety Sear 12M-12
P011406	Safety Sear 16-20-20M
P011408	Safety Sear Pin All Gauges
P011410	Safety Sear Spring All Gauges
P011414	Safety Sear Spring Follower All Gauges
P011421	Sight Ramp-Front-Buck Special 12M-12-16
P011422	Sight Ramp-Front-Buck Special 20M-20
SRFC.5	Stock, plain w/recoil pad
P011423	Sight Gold Bead-Front-Buck Special All Gauges
P011425	Sight Bead Plain & Vent Magnum 12M
P011431	Sight Bead Plain & Vent 12-20-20M-16
P011435	Tang Screw for Pistol Grip Stock All Gauges
P011444	Trigger-Crossbolt Safety-Gold Plated 12-16-20-20M
P011445	Trigger Pin All Gauges
P011466	Trigger Plate for Crossbolt Safety 12
P011473	Trigger Plate for Crossbolt Safety 16-20-20M
P011475	Trigger Plate Screw-Front-12M 12
P011477	Trigger Plate Screw-Front-16-20-20M
P011480	Trigger Plate Screw-Rear-12M-12
P011481	Trigger Plate Screw-Rear-16-20-20M
P011486	Trigger Spring Pin Retainer All Gauges
P011495	Trigger Spring Retaining Pin All Gauges
P011499	Magazine Plug Adapter 3 Shot All Gauges